



(c)



(d)

Parts Required -

- (a) Telescopic Lance
- (b) Sprayer Unit
- (c) Connecting Hose/Tube
- (d) 'T' Piece Adaptor

When connecting your MESTO sprayer to either our 3.2 metre or 5.4 metre telescopic lances you are connecting the SPRAYER TRIGGER HANDLE to the Telescopic Lance via the CONNECTING HOSE/TUBE. This gives you two options when spraying; either you use the spray lance, supplied with the sprayer, for close work or you use your Telescopic Lance for long distance work. The sprayer tank, hose, and trigger handle stay the same; you just connect a different lance depending upon the work you are doing.

1. Fully assemble your sprayer as per the instruction manual supplied.
2. Remove the REDUCER from the end of the TRIGGER HANDLE.
3. Attach the CONNECTING HOSE/TUBE to the sprayer TRIGGER HANDLE.
4. Connect the black plastic 'T' PIECE ADAPTOR to the threaded end of the TELESCOPIC LANCE.
5. Attach the free end of the CONNECTING HOSE/TUBE to the 'T' PIECE.
6. Push the thumb trigger on the TELESCOPIC LANCE down and forward to lock it in the ON position.

Your sprayer is now connected to the Telescopic Lance and you are ready to spray. The sprayer TRIGGER HANDLE is used to regulate the flow of liquid from your sprayer tank.

ACTUAL PIECES MAY DIFFER SLIGHTLY FROM THOSE SHOWN



(2)



(3)



(4)



(6)